What's in the package:

- 1* machine
- 2* microphones
- 1* Type C charging cable
- 1* DC 5V adapter
- 1* Aux cable
- 1* Strap

After-sale service

VinBridge provide one year warranty and lifetime technical support.

Toll Free Hotline: +1 (833) 996-2881 info@wwinbridge.com
 info@wwinbridge.com

http://www.winbridgestore.com Please be confident that seller support is just a mail away from you in case you find any difficulty, kindly do not hesitate to write back to

us if you need any clarification or any kind of support.





How to Monitor Music

Please plug a headset/headphone into the designated slot on the back of the machine. Your will listen or monitor music.

Cautionary Note

- 1. Please use the included adapter to charger speaker and microphone internal rechargeable battery;
- 2. Plug the adapter into 110-240 AC outlet;
- 3. It will take about 2.5 hours to fully charge the machine;
- 4. The machine prompts "DIDI" voice when it is lower battery, please charge it timely;
- 5. In order to extend the life of the internal battery, please charge even if system is not being used.
- 6. It is suggest that you charge the internal battery an additional 1-2 hours to extend its life.
- 7. Please do not over charge the battery by leaving the system plugged continuously. The will reduce the internal battery and cause over heating.

6

This machine will be ready to connect via Bluetooth as soon as you turn it on. Or please click the M button to switch Bluetooth mode, To use this feature, simply search for the machine name ("T8") under your playback device's Bluetooth connection settings and click to connect.

How to Use TF Mode

Playing music from an TF card

Plug your TF card into the designated slot on the back of the machine. Playback will begin immediately. Please make sure TF card has music file.

How to Use USB Mode

Playing music from a USB drive

Plug a USB stick into the designated slot on the back of the machine. Your music will begin playing automatically. Please make sure USB stick has music file. You can also use this slot to charge your phone using a compatible USB cable.


How to Connect to An External Media Source

Playing music from a MP3 Player, Phone, TV or musical


Plug the AUX, coax or musical instruments related cable into the designated slot on the back of the machine. Then, plug in your preferred compatible device into the other end of the adapter and use the machine as indicated.




Karaoke Machine Performance Manual



Top View:



Back View:



Quick Start Guide:

- #1 Charge the machine and microphones before each use;
- #2 Turn the machine and microphones on;
- #3 Choose your preferred playback setting;
- #4 Rock on;

Machine

How to Charge The Machine

Connect the USB adapter and a compatible type C cord into machine and to a polarized outlet. Be sure to charge fully before each use. While charging, the red light keep solid, then goes out when the battery is full.

How to Turn The Machine On

Long press Oto turn the power switch on

How to Turn LED Light On/Off

Long press O to turn the LED light on/off. Short press O to adjust different LED effects.

How to Adjust The Machine Volume

To adjust the machine volume, please rotate the button ((a)) up or down until it reaches your preferred volume.

Microphones

How to Connect Microphone to Machine

Turn microphones on using the power button on the handle, they will automatically connect to the machine.

How to Charge The Microphones

Connect the USB adapter and a compatible type C cord into microphones and to a polarized outlet. Be sure to charge fully before each use. While charging, the red light keep solid, then goes out when the battery is full.

How to Customize Your Microphone Vocal Mix

To adjust the volume of your singing over the music, click the MIC +/- buttons up or down until it reaches your preferred

To modify the reverb effect on your singing, click the Echo +/buttons up or down as desired. There are 4 sound effects available. (Laughter/Applaud/Man/Lady)

Music

How to Connect Bluetooth

Playing music from your device